



**BE1491**

Visit **baby monitor**





## Manufacturer


Bellman & Symfon Group AB  
Södra Långebergsgatan 30  
436 32 Askim Sweden  
Phone +46 31 68 28 20  
E-mail [info@bellman.com](mailto:info@bellman.com)  
[bellman.com](http://bellman.com)



Revision: BE1491\_084MAN1.0

Date of issue: 2022-02-21

TM and © 2022 Bellman & Symfon AB. All rights reserved.




# Baby monitor

BE1491


Brugervejledning	<b>DA</b>
Benutzerhandbuch	<b>DE</b>
User manual	<b>EN</b>
Manual del usuario	<b>ES</b>
Käyttöopas	<b>FI</b>
Mode d'emploi	<b>FR</b>
Gebruiksaanwijzing	<b>NL</b>
Brukerhåndbok	<b>NO</b>
Bruksanvisning	<b>SE</b>
Installer's guide	<b>EN</b>

## Översikt




## Montera

- 1 Dra bort batterilappen för att starta babyvakten.
- 2 Ställ babyvakten på nattduksbordet eller häng den på väggen med medföljande skruv och plugg. Lämpligt avstånd är 0,5–2 m, utom räckhåll från barnet.



## Testa

- 1 Ställ dig vid barnets säng och väsnas.
- 2 Din Visitmottagare indikerar då med ljud, ljus eller vibrationer (beroende på mottagare) och en upplyst nappsymbol. Om den inte reagerar, läs mer i avsnittet **Inställningar**.



## Inställningar

Knapparna för känslighet och födröjning sitter på babyvaktens vänstra sida. När du trycker på knappen visar lysdioderna aktuell inställning. Tryck sedan upprepade gånger för att justera inställningen.


- Om babyvakten inte aktiveras trots att babyn skriker – öka känsligheten.  
Om babyvakten aktiveras vid för svaga ljud – minska känsligheten.
- Om babyvakten aktiveras för snabbt eller långsamt – justera födröjningen.

### Känslighet

Röd diod	65 dB
Orange diod	75 dB
Grön diod	85 dB


### Födröjning

Röd diod	30 s
Orange diod	10 s
Grön diod	1 s



## Installera trampmatta

Genom att använda en trampmatta, kan du också få reda på om barnet tar sig ur sängen. Placera mattan framför spjälsängen och anslut den till babyvakten så talar den om när barnet trampar på den.



BE9026 Trampmatta  
(säljs separat)

## Teknisk information

Strömförsörjning

Batteridrift: 2 x 1,5 V AA (LR6) lithium eller alkaliska batterier.

Strömförbrukning  
Aktiv < 70 mA, Vänteläge < 400 µA

Alkaliskt batteri ~ 6 mån, Litiumbatteri ~ 1 år

Drifttid  
Aktivering  
Radiofrekvens  
Maximal uteffekt  
Räckvidd

Via testknappar, mikrofon och trampmatta kopplad till ext. trigg.  
868,3 MHz, 433,92 MHz eller 314,91 MHz beroende på region

4,7 dBm

50 - 250 m fri sikt beroende på radiofrekvens. Räckvidden reduceras  
av väggar, stora föremål och andra radiosändare.  
64 som standard. Upp till 256 med extra programvara.

Antal radionycklar

SE

## Övrig information



Observera: Se alltid till att babyvakten är utanför räckhåll för barnet. Placera aldrig  
babyvakten i barnets säng eller lekhage.

Användning, transport  
och lagring

Information om detta finns i **Installer's Guide**  
Underhållsfri. Rengör endast med mjuk duk. Använd inte rengörings-  
medel, lösningsmedel, ammoniak eller alkohol. Ej återanvändbar.

Rengöring och underhåll

Säkerhet  
Service och support

Information om bestämmelser och säkerhet finns i **Installer's Guide**.  
Information om garanti, service och support finns i **Installer's Guide**.

## Felsökning

Om	Gör så här
Lysdioderna blinkar orange varje 10:e sekund	<ul style="list-style-type: none"> <li>Byt batterier. Använd endast 1,5 V AA (LR6) litium eller alkaliska batterier.</li> </ul>
Lydioden lyser grönt utan att mottagaren aktiveras	<ul style="list-style-type: none"> <li>Kontrollera batterierna i mottagaren och babyvakten.</li> <li>Flytta mottagaren närmare babyvakten.</li> <li>Kontrollera att mottagaren och babyvakten är inställda på samma radionyckel. Se vidare under <b>Changing the radio key</b> i Installer's Guide.</li> </ul>
Babyvakten aktiveras inte trots att barnet skriker	<ul style="list-style-type: none"> <li>Flytta babyvakten närmare barnet eller öka mikrofonens känslighet. Se vidare under <b>Inställningar</b>.</li> <li><b>OBS!</b> Se alltid till att babyvakten är utom räckhåll för barnet. Placera aldrig babyvakten i barnets säng eller lekhage.</li> </ul>

Om	Gör så här
Babyvakten aktiveras för lätt	<ul style="list-style-type: none"> <li>Minska mikrofonens känslighet eller flytta babyvakten längre ifrån barnet. Se vidare under <b>Inställningar</b>.</li> </ul>
Babyvakten aktiveras för snabbt	<ul style="list-style-type: none"> <li>Öka fördräjningen på babyvakten. Se vidare under <b>Inställningar</b>.</li> </ul>
Babyvakten aktiveras för långsamt	<ul style="list-style-type: none"> <li>Minska fördräjningen på babyvakten. Se vidare under <b>Inställningar</b>.</li> </ul>
Visitmottagaren aktiveras utan anledning	<ul style="list-style-type: none"> <li>Det finns troligen ett annat Visitsystem i närheten som aktiverar din mottagare. Byt radionyckel på alla enheter. Se under <b>Changing the radio key</b> i Installer's Guide.</li> </ul>



# Installer's Guide

---

**78** Introduction

---

**80** Installation

---

**82** Testing

---

**84** Settings

---

**85** Default indication and signals

---

**86** Changing the radio key

---

**90** Trouble shooting

---

**92** Technical information

---

## Introduction

### Function

The baby monitor is part of the Visit alerting system that helps people with hearing loss to notice signals in their home. When your child cries, the baby monitor signals the Visit receiver that notifies you with sound, lights or vibrations (depending on the receiver). This way you are always close to your baby.

### Activation


The baby monitor can be activated by either:

- The test buttons (press simultaneously)
- The built-in microphone
- The BE9026 Contact mat accessory (connected to the Ext trig input)

### Settings


The baby monitor allows you to adjust the sensitivity and delay and you can set a unique signal for each child, so you know who needs your attention.

## Overview




## Installation

- 1 Remove the battery pull tab to start the baby monitor.
- 2 Place the baby monitor on the nightstand or hang it on the wall with the screw and plug. The recommended distance is 0.5 - 2 m, out of reach from the child.



## Installing a contact mat


By using a contact mat, you can also be notified if your child gets out of bed. Just place the mat in front of the crib, connect it to the baby monitor and it will tell you when your child steps on it.



BE9026 Contact mat  
(sold separately)

## Testing

- 1 Stand by the child's bed and make a noise.
- 2 The Visit receiver lights up a pacifier symbol and indicates with sound, lights or vibrations (depending on the receiver). If it doesn't react, read the section **Advanced testing**.



## Advanced testing

Testing the baby monitor is easy. First, make sure that the baby monitor is installed properly. For instructions, read the section **Installation**.

### Using the test button

Press both test buttons simultaneously.

- 1 The baby monitor's LED lights up to show that a radio signal is transmitted.
- 2 The receiver's pacifier symbol lights up to show that the signal was received.

### Using the microphone

Activate the baby monitor by whistling or speaking into the microphone.

- 1 The baby monitor's LED lights up to show that a radio signal is transmitted.  
*If you have adjusted the delay, it will be postponed as shown on page 84.*
- 2 The receiver's pacifier symbol lights up to show that the signal was received.  
*If you have customized the signal pattern, it will blink as shown on page 88.*

If it doesn't work as described, read the section **Troubleshooting**.

## Settings

The buttons for sensitivity and delay are located on the baby monitor's left side. When you press the button, the LED shows the current setting. Then press repeatedly to adjust the setting.


- If the baby monitor isn't activated when the baby cries – increase the sensitivity.  
If the baby monitor is activated too easily – reduce the sensitivity.
- If the baby monitor is activated too fast or too slow – adjust the delay.

### Sensitivity

Red LED	65 dB
Orange LED	75 dB
Green LED	85 dB

### Delay

Red LED	30 s
Orange LED	10 s
Green LED	1 s



## Default indication and signal

### Transmitter indication

When the baby monitor is activated, the LED indicator lights up in green. This means that the batteries are in good condition. If an orange light appears, it's time to change the batteries. Only use 1.5 V AA (LR6) lithium or alkaline batteries.

### Receiver signal

When a receiver is activated, it signals with sound, flashes or vibrations. The default signal pattern is as follows:

**Signal pattern**  868/315 MHz  433 MHz

Baby monitor		Receiver signal pattern			
Source	LED	LED	Sound	Vibration	Flash
Baby voice	Green, top	Orange light	Baby melody	Fast  Yes	Yes
Contact mat	Green, bottom	Green light	1x door chime, low	Slow  Yes	Yes
Baby voice	Green, top	Orange light	Baby melody	Long  Yes	Yes
Contact mat	Green, bottom	Green light	1x door chime, low	Long  Yes	Yes

## Changing the radio key

If you install multiple systems, you can set a unique radio key for each system to avoid interference. Move any radio key switch **A** to the up=on position to change radio key.

### Please note:


All Visit products within the same system must be set to the same radio key in order to operate as a group.

All radio key switches are positioned down=off per default.



## Customizing the signal

The baby monitor controls the signal pattern on the receiver. By moving a signal switch **B** up=on you can set a unique signal for each baby. Note that you need to move the other switches down.



## Signal output for 868 MHz and 315 MHz

Baby monitor		Receiver signal pattern			
Switch	Source	LED	Sound	Vibration	Flash
	Test button or Baby monitor 1	Orange light	Baby melody	Fast ■■■■■	Yes
	Contact mat 1	Green light	1 x door chime, low	Slow ■□□□	Yes
	Test button or Baby monitor 2	2 x orange blinks	Baby melody	Fast ■■■■■	Yes
	Contact mat 2	2 x green blinks	2 x door chime, low	Slow ■□□□	Yes
	Test button or Baby monitor 3	3 x orange blinks	Baby melody	Fast ■■■■■	Yes
	Contact mat 3	3 x orange blinks	Baby melody	Fast ■■■■■	Yes
	Test button or Baby monitor 4	Orange blinks	Baby melody	Fast ■■■■■	Yes
	Contact mat 4	Orange blinks	Baby melody	Fast ■■■■■	Yes

## Signal output for 433 MHz

Baby monitor		Receiver signal pattern			
Switch	Source	LED	Sound	Vibration	Flash
	Test button or Baby monitor 1	Orange light	Baby melody	Long ■■■■■	Yes
	Contact mat 1	Green light	1 x door chime, low	Long ■■■■■	Yes
	Test button or Baby monitor 2	Orange light	2x ring signal, low	Medium ■□■□	Yes
	Contact mat 2	Green light	1x ring signal, high	Medium ■□■□	Yes
	Test button or Baby monitor 3	Orange light	2x door chime, low	Long ■■■■■	Yes
	Contact mat 3	Orange light	2x door chime, low	Long ■■■■■	Yes
	Test button or Baby monitor 4	Orange light	Baby melody	Long ■■■■■	Yes
	Contact mat 4	Orange light	Baby melody	Long ■■■■■	Yes

## Trouble shooting

If	Try this
<b>A green light appears on the baby monitor but the receiver is not activated</b>	<ul style="list-style-type: none"> <li>Check the baby monitor's and the receiver's batteries and plugs.</li> <li>Move the receiver closer to the baby monitor.</li> <li>Check that the baby monitor and the receiver are set to the same radio key. For more information, read the section <b>Changing the radio key</b>.</li> </ul>
<b>The baby monitor is not activated even though the baby is crying</b>	<ul style="list-style-type: none"> <li>Move the baby monitor closer to the baby or increase the microphone's sensitivity, see <b>Settings</b>.</li> <li><b>Please note:</b> Always make sure the baby monitor is out of the child's reach. Never place the baby monitor in the child's crib or playpen.</li> </ul>

If	Try this
<b>The baby monitor is activated <i>too easily</i></b>	<ul style="list-style-type: none"> <li>Reduce the sensitivity or move the baby monitor further away from the crib, see <b>Settings</b>.</li> </ul>
<b>The baby monitor is activated <i>too fast</i></b>	<ul style="list-style-type: none"> <li>Increase the delay. For more information, read the section <b>Settings</b>.</li> </ul>
<b>The baby monitor is activated <i>too slow</i></b>	<ul style="list-style-type: none"> <li>Reduce the delay. For more information, read the section <b>Settings</b>.</li> </ul>
<b>The receiver is activated for no reason</b>	<ul style="list-style-type: none"> <li>There is probably another Visit system nearby that triggers your system. Change the radio key on all units, see <b>Changing the radio key</b>.</li> </ul>
<b>Two orange lights appear every 10s</b>	<ul style="list-style-type: none"> <li>Change the batteries. Only use 1.5 V AA (LR6) lithium or alkaline batteries.</li> </ul>

## Technical information

### Power supply

Battery power: 2 x 1.5 V AA (LR6) lithium or alkaline batteries.

### Power consumption

Active < 70 mA, Idle position < 400 µA

### Operating time

Alkaline ~ 6 months, Lithium ~ 1 year

### Activation

Via the test buttons, microphone or a contact mat via the ext trig

### Radio frequency

314.91 MHz, 433.92 MHz or 868.3 MHz depending on region

### Coverage

50 - 250m (55 - 273yd) depending on radio frequency. Coverage is reduced by walls, large objects and other radio transmitters.

### Number of radio keys

64 as standard. Up to 256 with optional software.

## Additional information

### Security

 Always make sure the baby monitor is out of the child's reach.  
Never place the baby monitor in the child's crib or playpen.

### Operating temperature

0° – 35° C, 32° – 95° F

### Transport and storage temp.

-10° – 50° C, 14° – 122° F

### Relative humidity

15% – 90% (non condensing)

### Maintenance and cleaning

Maintenance free. Clean with a dry cloth. Don't use household cleaners, aerosol sprays, solvents, alcohol, ammonia, or abrasives.

### Warranty and service

If the product appears to be damaged or doesn't function properly, follow the advice in this booklet. If it still doesn't function properly, contact your retailer for info about obtaining warranty service.

## FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: WMSBETXBC

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For a complete Declaration of Conformity please contact the Bellman & Symfon European office.

## Industry Canada statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interfe-

rence.(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with the Canadian ICES-003.

IC: 6693A-BETXTE2

## Zusätzliche Information

Nur Innen verwenden. Wartungsfrei. Reinigung mit einem nur leicht feuchten Tuch.

HMV 16.99.09.0045