

Visit accessories

Magnetic mount kit

For easy installation of smoke alarms

The magnetic mount kit offers a quick and easy alternative to traditional screws and plugs. It consists of a self-adhesive plate that you fix to the ceiling and a self-adhesive magnetic plate that you attach to your smoke alarm.

Installation procedure

- 1 Remove the protective film from the non-magnetic plate.
- 2 Mount the plate on the ceiling and hold for 10 s.
- 3 Remove the protective film from the magnetic plate and attach it to the smoke alarm. Hold for 10 s.
- 4 Place the smoke alarm on the ceiling plate.

Please note

The mounting kit is not suitable for vinyl wallpapers, anti-adhesive coatings, silicone-coated or Teflon-coated surfaces. The diameter of the smoke alarm cannot be less than 70 mm.

Technical specifications

- Diameter 70 mm
- Weight 25 g
- Color White
- Environment For indoor use only

BE9175

