

Visit accessory



Magnetic mounting kit

For easy installation of smoke alarms

The magnetic mount kit offers a quick and easy alternative to traditional screws and plugs. It consists of a self-adhesive plate that you fix to the ceiling and a self-adhesive magnetic plate that you attach to your smoke alarm.

Note: The mounting surface must be clean from dust and grease. Failure to clean surface properly may cause unit to fall down prematurely. Don't use household cleaners like wipes or sprays as they may leave a slippery residue. The kit is not suitable for vinyl wallpapers, anti-adhesive coatings, heavily structured surfaces, silicon-coated or Teflon-coated surfaces. The diameter of the smoke alarm cannot be less than 70 mm.

Installation procedure

- 1 Wipe the surface gently using isopropyl rubbing alcohol.
- 2 Remove the protective film from the non-magnetic plate.
- 3 Mount the plate on the ceiling and hold for 10 s.
- 4 Remove the protective film from the magnetic plate and attach it to the smoke alarm. Hold for 10 s.
- 5 Place the smoke alarm on the ceiling plate.

Technical specifications

- Diameter 70 mm
- Weight 25 g
- Color White
- Environment For indoor use only

