



Magnetic switch

Monitors the door and window

Mount the magnetic switch on the door or window frame and connect it to the telephone transmitter. When the magnets are separated, the transmitter signals the Visit receiver.

Technical specifications

- Dimensions 25×62×13 mm, 1"×2.5"×0.5"
- Weight 25 g, 0.9 oz.
- Connector 3.5 mm mono jack plug
- Cable length 0.5 m, 1.6'
- Contact breaker
 - Switch ON (door opened) > 2 cm, 0.8" from the magnet
 - Switch OFF (door closed) < 1 cm, 0.4" from the magnet
- Color White
- Environment For indoor use only

