

# Pager charger

BE1260



## Features

**Night-time alerts**  
Alerts you with vibrations

**Bed shaker outlets**  
Supports two bed shakers

**Battery backup**  
Works even during power loss

## Charger for the Visit pager.

The pager charger from Bellman & Symfon is specially designed for the Visit smart home system and is used to recharge the Visit pager battery.

The pager alerts you even during charging, just connect a bed shaker to the charger to wake up to vibrations if a Visit transmitter is activated while you are resting. The charger features backup batteries and remains fully functional during power loss, so you can get a peaceful sleep.

### Technical specifications

- Dimensions 78 x 88 x 43 mm, 3" x 3.5" x 1.7"
- Weight, with battery 385 g, 13.6 oz.
- Mains power 7.5 VDC / 1500 mA
- Backup battery Internal NiMH batteries
- Vibrator power 2.0 - 4.0 VDC
- Accessories:
  - BE1270 Bed shaker
  - BE9086 Trigger cable
- For indoor use only

Connect up to two  
Use output B



© 2020, Bellman & Symfon AB. All rights reserved.  
Bellman, Bellman & Symfon and the Bellman & Symfon logo are registered trademarks of Bellman & Symfon AB. This leaflet is subject to change without prior notice.