Mobile phone sensor

Art. no. BE9250





NEW! Now we introduce the Mobile phone sensor that connects the mobile phone or tablet to the Visit alerting system. It will tell your clients when they receive a call or message, even if they are several rooms away.

When the display lights up, the mobile phone sensor activates the Visit system that notifies the client with sound, flashes or vibrations.



TECHNICAL INFORMATION

Placement	Horizontally on the display	
Optical detection	Activated when the display lights up	
Light sensitivity	Visible light >3 lux	
Battery	1 x AAA 1.5 V alkaline	
Operating time	> 1 years under normal use	
Connectors	Mobile phone sensor: 2.5 mm tele plug Adapter: 3.5mm tele plug	
Connections	Can be connected to all Bellman & Symfon products that feature an external trigger connector like for example BE1430, BE1123 and BE1370	
Weight	Mobile phone sensor: 20 g Adapter: 27g (with battery)	
Color	White	

ADDITIONAL INFORMATION

Ergonomic design	Ideal for people with impaired vision or limited dexterity
Low center of gravity	Resumes an upright position if it is knocked over
Usage	For indoor use only