## Visit smoke alarm

BE1281







#### **Features**

#### Optical

Photoelectric IR sensor

#### **Battery supervision**

Warns if the battery runs low

#### **Toast mode**

For areas with cooking fumes

#### Reliable radio link

Covers your entire home

# Protect your home and family.

The smoke alarm from Bellman & Symfon is part of the Visit smart home system that helps you to keep tabs on your home. It discovers smoke and smoldering fire at an early stage and relays the alarm directly to your Visit receiver.

#### Watches out for you

If a fire starts, the smoke alarm instantly relays the signal to your Visit receiver that alerts you with sounds, flashes or vibrations (depending on the receiver). Visit will give you an early warning, so you can get out of harm's way in time.

The smoke alarm uses a highly reliable radio link that covers your entire home. It is robust and features state-of-the-art battery supervision that automatically notifies you when the batteries run low. It is also equipped with toast mode to avoid false alarms while you are cooking.





#### Dimensions and weight

**4.7**", **120** mm Height: Width: **4.7**", **120** mm Depth: 1.8", 46 mm

Weight: **6.5** oz, **185** g incl. battery



4.7", 120 mm

#### **Features**

- Sensor type Photoelectric, reflection system by IR sensor
- Smoke sensitivity 0.9% to 1.8% OBS/Ft
- Audible alarm > 85 dB(A) @ 10' (3m)
- Toast mode silencer feature Provides a 10 min sensitivity reduction
- Radio connection Features a separate PCB radio module mounted in the detector
- Low battery warning The low battery warning signal sounds for min. 7 days when battery replacement is needed.
- Front indicator LEDs Smoke alarm LED - Red Radio module LED - Green

#### Regulatory requirements

■ BE1281 complies with the following smoke alarm standards: UL 217, CAN-ULC-S531

#### **Buttons and controls**

Test & silence button Smoke alarm LED (ES)

#### **Power and battery**

Power supply Duracell MN1604 alkaline 9V replaceable battery

Radio module LED

- Power consumption Standby ~ 20µA
- Operation time: Over 1 year

• 64 as standard. Up to 256 with optional software.


### Number of radio keys

#### **Environmental requirements**

- For indoor use only
- Temperature range: 32° to 100° F (0° to 38° C)
- Humidity range:15% to 95% R.H. (non-condensing)

#### Frequency and coverage

- Radio frequency: 433.92 MHz and 434.33 MHz
- Coverage: ~ 66 yd, 60 m clear line of sight. Radio coverage depends on the building's characteristics and local radio conditions.



#### In the box

- BE1281 Smoke alarm
- 1 x 9V alkaline batterv
- Mounting plate
- Screws and plugs
- User manual



#### Maintenance and cleaning

- Vacuum your smoke alarm regularly (and always when the battery is replaced) with the soft brush and wipe the unit with a slightly damp cloth.
- Warning: Do not paint over the smoke alarm.

#### © 2016 Bellman & Symfon AB. All rights reserved.

Bellman, Bellman & Symfon and the Bellman & Symfon logo are registered trademarks of Bellman & Symfon AB. This leaflet is subject to change without prior notice.

BE1281\_001DAS002

bellman.com