

Alarm clock, Classic model

BE1350

 Bellman & Symfon®



Features

- 1 Extra loud 100dB* alarm**
Ascending multi-tone signal
- 2 Smart Snooze**
Reduces the snooze interval
- 3 Powerful bed shaker**
Vibrates under your pillow
- 4 Battery backup**
Keeps all features functional

100 dBA @ 10 cm, 4", 94 dBA @ 30 cm, 12"



Waking up has never been easier

With the Classic Alarm clock from Bellman & Symfon you no longer have to worry that you might oversleep. Choose to wake up to an extra loud and audible alarm and a bed shaker that vibrates under your pillow. Perfect if you have a hard time getting out of bed or have trouble hearing.

The Classic Alarm clock has many unique features like the smart snooze function that reduces the time intervals from 9 to 2 minutes

and the multiple tone alarm signal that sweeps through the frequencies so that, even if you have trouble hearing for instance high frequencies, you will not miss it. The Classic Alarm clock is very easy to use. It has a large LCD display with adjustable back light and two separate push-rotate dials for setting the time and alarm.

In addition, you can turn off the sound signal so that you don't disturb others when you need to get up.



Technical specifications

Size and weight

- Height: **108 mm, 4.3"**
Width: **121 mm, 4.7"**
Depth: **92 mm, 3.6"**
Weight: **390 g, 13.7 oz, incl. batteries**



Buttons and controls



In the box

- BE1350 Alarm clock
- BE1271/ BE1272 Bed shaker (depends on different market)
- Power adapter, 7.5 VDC, 1500 mA
- User guide



Output signals

- **Sound**
100 dBA @10 cm, 4", 94 dBA @ 30 cm, 12"
Built-in multiple frequency signal with a main frequency of 950 Hz - 3000 Hz
- **Bed shaker**
Vibrator power: 2.0 - 4.0 V DC

Display

- Type: Twisted Nematic (TN) LCD
- Adjustable backlight intensity in 5 steps
The backlight is activated by the snooze button
- Backlight color: white
- Display timeout: 8 seconds

Operation

- Separate push-rotate dials for easy setting of the time and alarm
- Dedicated button that switches between 12-hour and 24-hour time format
- Dedicated button that adjusts the backlight intensity in five steps
- Dedicated button that turns on / switches off the alarm sound
- Battery supervision that monitors and displays the backup battery status.
- The backup battery powers the sound and the bed shaker. (Batteries not included)

Accessories

The following accessories are available:

- 4 x rechargeable AAA size NiMH batteries

Environmental requirements

- Operating temperature: 32° to 95° F (0° to 35° C)
- Relative humidity: 15% to 90% (non condensing)

Alarm and snooze

- Alarm timeout: 20 minutes
- Decreasing snooze time interval from 9 to 2 minutes in two minutes steps

© 2020, Bellman & Symfon AB. All rights reserved.

Bellman and Bellman & Symfon are registered trademarks owned by Bellman & Symfon AB, all rights reserved. This leaflet is subject to change without prior notice.

BE1350_018DAS005_EN

bellman.com